

Wilo-RAIN3








de Quick Start Guide







en Quick Start Guide







fr Quick Start Guide

nl Quick Start Guide













7







8



i



Distance > 20 m
Diameter < 1'' / 32x3





















9





i








i Navigation im Menü
Menu Navigation
Navigation dans le menu
Menu navigatie




i Einstellung Parameter
Parameter Setting
Réglage des paramètres
Parameterinstelling






19 Auswahl Menüsprache
Menu language selection
Sélection de la langue du menu
Selectie van menutaal




i Fehlerbehebung
Error correction
Correction des erreurs
Foutcorrectie







20 Einschalten der Antriebe
Switch-on of drives
Mise en marche de la pompe
Inschakelen van aandrijvingen



21




22





Level 2





≡	>	5.0	>	5.51	: 250 cm
>		5.24			: [5.51] + 25 cm
>		5.22			: 25 cm
>		5.52			: [5.22] + 10 cm
>		5.53			: [5.52] + 10 cm
>		5.26			: -
		5.29			:




Level 2



≡	>	1.0	>	1.04	: 1,2 bar
					: 3,5 (Hi-Multi3-24) /
					4,4 (Hi-Multi3-25) /
					4,9 (Hi-Multi3-45)
>		3.0	>	3.02	: Auto
>			>	3.06	: Auto



≡	>	3.0	>	3.03	: Auto
>		5.0	>	5.05	: 0





Local contact at
www.wilo.com/contact

HYDROLYSE